

Instruction Manual HP7

1. Technical Description

	HP7-230	HP7-110	
Supply Voltage:	230V / 50/60Hz	110V / 50/60Hz	
Power:	180W / 0,8A	180W / 1,6A	
Temp. :	30 - 110°C	30 - 110°C	
Temp. Accuracy:	± 20°C	± 20°C	

Inner Dim WxHxD:	75x105x450 mm	75x105x450 mm
Ext. Dim WxHxD:	150x135x550 mm	150x135x550 mm
Weight:	5 kg	5 kg
Capacity:	6 kg	6 kg

HP7 is a quiver made in brushed stainless steel 1.4016. HP7 has a variable thermostat (30-110°C) and an indicator lamp that shows when the quiver is plugged in. The heater inside the quiver is located in the middle to give the best heating result on all welding rods. It is insulated all around to keep the heat inside the quiver; this makes it both safer and saves energy.

2. Safety



- Connect the HP7-230 to grounded supply 230V only and HP7-110 to grounded supply 110V only.
- The wrapping must be removed before placing the rods in HP7.
- Do not use HP7 in explosive or flammable areas.
- Keep hatch closed.
- Use gloves when handling the goods to avoid injuries.
- There are no user-serviceable parts inside. Refer servicing to supplier.

ElectroHeat Sweden AB Box 8065 402 78 Göteborg Phone: +46 31 764 36 30 Fax: +46 31 54 47 02 Email: info@electroheat.se

VAT No: SE556101713701

Internet: www.electroheat.se